



WCFab Turbo Heat Blankets

Covers installation of PN: WCF100822, WCF100732, WCF100731 & WCF100733



Note: Our heat blankets are designed to retain heat, not block heat from outside sources. DO NOT install heat blanket if exterior will make contact with exhaust components or sharp objects. This will quickly deteriorate exterior of heat blanket and will not fall under manufacturer's defect for warranty purposes.

Items for install: 1 pair of gloves to avoid getting fiberglass in hands and a pair of heavy duty scissors/wire cutters for trimming safety wire.

1. Locate supplied safety wire and cut two 10" lengths.
2. Take each piece of safety wire and create a loop around each rear hook on back of blanket.



3. Install heat blanket around exhaust housing (shown off truck for display purposes) and snug it down by hooking safety wire around opposing loop to pull it tight. **Please be aware, heat blankets on VGT turbos will require factory heat shield to be removed.**



4. At this point, heat blanket is installed and functional. To keep it clean, we recommend using a damp rag and degreasing dish soap to clean grease/oil from the heat blanket. **DO NOT use brake clean or any other flammable liquids to clean heat blanket, as it will act like a sponge and potentially cause a fire.**

Any Questions, Comments, or Feedback?

Reach us by Email - Sales@wcfab.com

Or the shop phone - 630-277-8239

Thank you for purchasing from Wehrli Custom Fabrication!